

## DATASHEET

# ACTSAFE RCX RESCUE ASCENDER



### GENERAL

Art.Nr:	POA-017
GTIN:	4030281299875
Customs tariff number:	84253100

Net weight:	30.00 kg
Gross weight:	30.00 kg

## DATASHEET

# ACTSAFE RCX RESCUE ASCENDER

The battery-powered ActSafe RCX power ascender is a motorised system to ensure the transport of persons to hard-to-reach areas where occasional or repetitive work is carried out. The ActSafe RCX is a rope hoist that has been specially developed for effortless and efficient rescue operations. The main users are search and rescue (SAR) teams from the fire brigade, disaster relief or emergency services. The innovative device is compact, lightweight and complies with protection class IP67 (dustproof and waterproof). It is equipped with replaceable and rechargeable batteries and a remote control with a range of up to 150 metres. The ActSafe RCX is perfectly suited for ropes with different diameters and is therefore flexible and quickly ready for use. The device is certified for a user weight up to 250 kg.

- Simplifies and accelerates work during rescue operations
- 0-24 m/minute at 250 kg, IP67 standard
- Variable rope grab system

### FEATURES

Application areas:	Various
Colour:	Red, Yellow
Number of Rechargeable Batteries:	2
Battery range at 20° C & 100 kg load:	550 m
Energy source:	Removeable Battery, POA-004 power supply
Underwater operations:	No
Water dust resistance:	IP 67
Charging time:	90 minutes
Max. noise level:	76 dB(A)
Min. noise level:	0 dB(A)
Minimum compatible rope diameter:	6.00 mm
Maximum compatible rope diameter:	11.00 mm
Minimum descent speed:	0 m/min
Maximum descent speed:	25 m/min
Min. ascent rate:	0 m/min
Max. ascent rate:	24 m/min
Minimum temperature:	-10 °C
Maximum temperature:	40 °C
Emergency descent function:	Yes
Emergency stop function:	Yes
Remote control range:	150 m

## DATASHEET

# ACTSAFE RCX RESCUE ASCENDER

Working Load Limit: 250 kg

---

### **MATERIAL**

Material: Steel, Aluminium,  
Nylon

---